

		Messbereiche (Hinweis auf DIN)													
		Überdruck- und Unterdruckmessung elektronisch											bar		
Datenblatt AZB/ DE04	MessSystem	piezoresistiv		Dünnschicht DMS		Dickfilm		Keramik		kapazitiv ¹⁾		photooptisch		DIN	
	Güteklasse ± % v. Endwert	≤0,5%	>0,5%	≤0,5%	>0,5%	≤0,5%	>0,5%	0,3%	≥0,5%	≤0,5%	>0,5%	0,05%	0,15%	Kenn- zahlen	
Druck- spanne (bar)	Mess- bereich														
1	0...1,0	●	●	●	●	—	●	●	●	—	—	●	●	025	
	-1...0	●	●	●	●	—	●	●	●	—	—	●	●	315	
1,6	0...1,6	●	●	●	●	—	●	●	●	—	—	●	●	035	
	-1...0,6	●	●	●	●	—	●	●	●	—	—	●	●	505	
2,5	0...2,5	●	●	●	●	—	●	●	●	—	—	●	●	045	
	-1...1,5	●	●	●	●	—	●	●	●	—	—	●	●	515	
4	0...4	●	●	●	●	—	●	●	●	—	—	●	●	055	
	-1...3	●	●	●	●	—	●	●	●	—	—	●	●	525	
6	0...6	●	●	●	●	—	●	●	●	—	—	●	●	065	
	-1...5	●	●	●	●	—	●	●	●	—	—	●	●	535	
10	0...10	●	●	●	●	—	●	●	●	—	—	●	●	075	
	-1...9	●	●	●	●	—	●	●	●	—	—	●	●	545	
16	0...16	●	●	●	●	—	●	●	●	—	—	●	●	085	
	-1...15	●	●	●	●	—	●	●	●	—	—	●	●	555	
	-1...12,5	●	●	●	●	—	●	●	●	—	—	●	●	925	
25	0...25	●	●	●	●	—	●	●	●	—	—	●	●	095	
	-1...24	●	●	●	●	—	●	●	●	—	—	●	●	565	
	-1...25	●	●	●	●	—	●	●	●	—	—	●	●	935	
40	0...40	●	●	●	●	—	●	●	●	—	—	●	●	105	
	-1...40	●	●	●	●	—	●	●	●	—	—	●	—	945	
50	0...50	●	●	●	●	—	●	●	●	—	—	●	●		
	0...60	●	●	●	●	—	●	●	●	—	—	●	●	115	
60	0...60	●	●	●	●	—	●	●	●	—	—	●	—	955	
	-1...60	●	●	●	●	—	●	●	●	—	—	●	—		
100	0...100	●	●	●	●	—	●	●	●	—	—	●	●	125	
160	0...160	●	●	●	●	—	—	●	●	—	—	●	●	135	
250	0...250	●	●	●	●	—	—	●	●	—	—	●	●	145	
400	0...400	●	●	●	●	—	—	●	●	—	—	●	●	155	
600	0...600	—	—	●	●	—	—	—	—	—	—	●	●	165	
1000	0...1000	—	—	●	●	—	—	—	—	—	—	—	●	175	
1400	0...1400	—	—	●	●	—	—	—	—	—	—	—	●		
1600	0...1600	—	—	●	●	—	—	—	—	—	—	—	●	185	
2500	0...2500	—	—	●	●	—	—	—	—	—	—	—	—	195	
4000	0...4000	—	—	●	●	—	—	—	—	—	—	—	—	205	

¹⁾ Medium Luft und nicht korrosive Gase

● = möglich — = nicht möglich
 (bezieht sich auf Geräte die erprobt und bereits im Markt eingeführt sind)